

FIG. 1




FIG. 2





FIG. 3

Workstation Software Architecture



09552626 - 09552606

FIG. 4




FIG. 5




FIG. 6




FIG. 7

Normal Sign On Message Sequence




FIG. 8

Normal Sign Off Message Sequence




FIG. 9

HeadSet Unjack Logoff Message Sequence




FIG. 10

Inbound Call Message Sequence





FIG. 11

Sample Dial Number Dialog



09576366 • 88222600

FIG. 12

Outbound Message Sequence




FIG. 13

Call Hold and Unhold Message Sequence




FIG. 14

Call Transfer to Outside Number




FIG. 15

Call Conference with Supervisor




FIG. 16

Operator Hangup
with
DisconnectCall
Key Message Sequence




FIG. 17

PlusTapi Utility Mode Panel

- PlusTcp conversation number for telephony support (1-8)
- TCP/IP address of telephony support (or "LocalHost")
- TCP/IP port number of telephony support
- Timeout for initialization of telephony support (seconds)
- Timeout for establishing telephony connection (seconds)
- Timeout for allowing operator to replug headset (seconds)
- TCP/IP address of Call Director Custom Server
- TCP/IP address of Voice Over Data Custom Server

FIG. 18


Sample InfoWin Utility Settings for CSW

-Field1-	-Field4-	-Field5-		-Field3-		-Field11-	-Field9-
-Field2-	-Field6-	-Field7-		-Field13-		-Field12-	-Field10-

09575466 • 0222206

FIG. 19

Sample CSW Running in Normal Mode



09876543210 9876543210

FIG. 20

